




BOX 1050

Box 1050 is appropriate for both residential and light commercial buildings. It is the most popular profile and for a good reason — it offers 25% wider coverage than similar profiles from other roofing suppliers! The Box 1050 gives you peace of mind by saving you money on material cost, accessories, and labor.

PRODUCT SPECIFICATIONS

Overall Cover Width: 1100mm
Effective Width Cover: 1050mm
Length: Customized to preference
Base Material: Zinc
Paint: Superior paint quality with eco-friendly properties.
Finish: Plain and Wrinkle
Thickness: 0.32mm, 0.4mm
Minimum Gauge: 28G
Maximum Gauge: 26G



BENEFITS

- Quick and easy to install.
- Long life span.
- High heat resistance.
- Conveniently handled on the site due to its lightweight.
- Chemical resistance.
- Eco-friendly.



We offer fast and free delivery, nationwide.

APPLICATION

- Institute project
- Roof cladding
- Side cladding
- Decking
- False ceiling

EFFECTIVE COVER	STOCK LENGTH	GAUGES	MIN LENGTH	MAX LENGTH
1050 MM± 5	2.0M, 2.5M, 3M & CUSTOM LENGTH	28 (G)	0.5M	6M
		26 (G)	0.5M	6M

To learn more about our wide variety of products please visit:
www.rafikiroofingmabati.com/shop

ROOF PROFILE



Overall Cover Width: 1100mm



TEAM RAFIKI



BOX 1050 FIXING GUIDELINES

FIXING ROOF

At eaves and ridge purlins, there are two fixings per purlins/sheet, whereas all intermediate purlins need one fixing in overlap only. This pattern has to be altered for locations exposed to heavy storms and wind pressure.

RECOMMENDED FOR CLADDING / VALLEY FIXING PATTERNS

Steel Girts:

For every alternate valley, use no. 12 x 20mm screw.

Timber Girts:

Use no. 20 x 25mm woodscrews for every alternate valley pressure.

To get an estimate,
scan the QR Code, or
contact our offices on:
+254 20 7658103
+254 706 012 345



TEAM RAFIKI

ROOF FIX DIAGRAM



RECOMMENDED FOR ROOFING / CREST FIXING PATTERNS

For Steel Purlins:

For crests along with the purlins, use 12 x 65mm screws and use stitching screws along the side lap at 600mm spacing.

For Timber Purlins:

For alternate crests along with the purlins, use 12 x 65mm self-drilling woodscrews and stitching screws along the side lap at 600mm spacing.

